SM and MM, 1260-1625nm, bidirectional





DATASHEET





Applications

- Network
- Data Storage
- Sensor System
- Instrument

Features

- Compact
- Low Cost
- High Reliability

The MEMS NxN Fiber Optical Switch is based on a reflecting silicon mirror that directs light from an input fiber to the requested output fiber among the N output fibers. The light path length difference between each state is small. The switch is bidirectional. It is available in single mode, polarization maintaining, and multimode. NXM is produced by cascading multiple 1xN in a compact format. The matrix switch is truly independent, with little hit interferences during the switching. N and M are available up to 160 with any number of combinations. It comes mounted on a PCB with control electronics powered by 5VDC. TTL control interface is standard. USB or RS232 with GUI is achieved through an optional adapting board that comes with a wall pluggable power supply and a computer interface cable.

Specifications

Parameter		Min	Typical	Max	Unit	
Wavelength	SM	1260		1625	nm	
vvaveleligili	MM	850		1450		
	4x4		1.4	1.6	dB	
1	8x8		1.6	1.8		
Insertion Loss [1]	12x12		1.9	2		
	32x32		2.4	2.6		
	64x64		2.6	3.0		
	4x4	50				
Cross Talls On Off	8x8	50				
Cross Talk, On/Off	12x12	45			dB	
	32x32	45				
	64x62	45				
Return Loss [3]		45		50	dB	
Repeatability		0.03		0.1	dB	
Polarization Dependent Loss				0.2	dB	
Wavelength Dependent Loss [4]				0.3	dB	
Temperature Dependent Loss				0.3	dB	
Switching Time			5	15	ms	
Optical Power Handling			300	500	mW	
Life Time		10 ⁹			cycle	
Operating Temperature		-20		70	°C	
Storage Temperature		-40		80	°C	
Power Supply		0		5	VDC	
Power Consumption				10	W	

Notes:

- [1]: measured without connectors @CWL ±30nm, 23°C: each connector adds 0.3dB. 0.7dB for 8 ch, 1dB for 12 ch, 1.2dB for 24 ch., 1.4dB for 32 ch., 1.5dB for 48 ch, 1.6 dB for 64 ch.
- [2]: 30dB for multimode fiber, 45dB for >single mode 24 ch., 50dB for < single mode 16 ch.
- [3]: 30dB for multimode fiber, 50dB for single mode
- [4]: @CWL \pm 30nm, 23°C

Legal notices: All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind Agiltron only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with the use of a product or its application.

Rev 12/05/23

© Photonwares Corporation

P +1 781-935-1200






SM and MM, 1260-1625nm, bidirectional






Optical Path Diagram

Switchable fiber loops in series



Mechanical Dimensions (mm)



© Photonwares Corporation

P +1 781-935-1200

E sales@photonwares.com


www.agiltron.com

SM and MM, 1260-1625nm, bidirectional





Typical Insertion Loss vs Wavelength (1240-1630nm)







SM and MM, 1260-1625nm, bidirectional





DATASHEET

Ordering Information

Prefix	Configuration	Wavelength	Control	Fiber Type	Fiber Cover	Fiber Length	Connector
MSWM-	4x4 = 0404 8x8 = 0808 12x12 = 1212 16x16 = 1616 24x24 = 2424 32x32 = 3232 48x48 = 4848 64x64 = 6464 	1240-1630nm = 1 1550nm = 5 1310nm = 3 1310/1550nm = B 850nm = 8 850/1310 = C 1060nm = 6	TTL = 1 USB = 2 RS232 = 3 Special = 0	SM28 = 1 50/125 = 2 Hi1060 = 3 PM1550 = 5 Special = 0	Bare fiber = 1 900um tube = 3 Special = 0	0.25m = 1 0.5m = 2 1.0m = 3 Special = 0	None = 1 FC/PC = 2 FC/APC = 3 SC/PC = 4 SC/APC = 5 SC/UPC = S ST/PC = 6 LC/PC = 7 MTP = 9 LC/UPC = U Special = 0

Driver Part Number: SWDR-MEMSNXM11

Fiber Core Alignment

Note that the minimum attenuation for these devices depends on excellent core-to-core alignment when the connectors are mated. This is crucial for shorter wavelengths with smaller fiber core diameters that can increase the loss of many decibels above the specification if they are not perfectly aligned. Different vendors' connectors may not mate well with each other, especially for angled APC.

Fibers with smaller core diameters (<5 µm) must be kept extremely clean, contamination at fiber-fiber interfaces, combined with the high optical power density, can lead to significant optical damage. This type of damage usually requires re-polishing or replacement of the connector.

Maximum Optical Input Power

Due to their small fiber core diameters for short wavelength and high photon energies, the damage thresholds for device is substantially reduced than the common 1550nm fiber. To avoid damage to the exposed fiber end faces and internal components, the optical input power should never exceed 20 mW for wavelengths shorter 650nm. We produce a special version to increase the how handling by expanding the core side at the fiber ends.

SM and MM, 1260-1625nm, bidirectional





DATASHEET

USB/TTL Driver Description

The MSWH MEMS NXM Driver is compatible with MEMS NxM switches (Up to 64 ports). It has three control modes: Onboard Switch; TTL; USB (Virtual COM) with a user-friendly GUI Windows™ program supporting UART commands. It is intended for convenient laboratory use or switch performance evaluation. The unit has a mini USB connector with a USB-to-MicroUSB cable. It can be powered by 5V USB cable and USB power supply or via onboard 5V-GND holes.

Mechanical Dimension

Manual Operation Instruction

· Power the Board

The unit can be powered up via 5V USB power supply.

· Onboard Switch Control

Onboard DIP-6 switch is available for quick TTL function test and fast manual control. After setting the DIP-6 switch, press the STROBE button to change the channel of MEMS 1xN switch.

SM and MM, 1260-1625nm, bidirectional





DATASHEET

TTL Operation Instruction

• TTL Interface Definition

Name	Direction	Descri	Description					
5V	Power		The driver board can also be powered up via these two					
GND	Ground	holes.	holes.					
D0-D5	Input	6 Pin 1	6 Pin TTL					
STR	Input	STROE	STROBE, Send a pulse to set the switch channel					
RST	Input	RESET	RESET, Send a pulse to reset switch status					
BUSY	Output	Logic	Logic HIGH when the device is busy					
ALARM	Output		Logic HIGH when the device meets error when booting/ high temperature					
СН	D5	D4	D3	D2	D1	D0		
1	0	0	0	0	0	0		
2	0	0	0	0	0	1		
3	0	0	0	0	1	0		
64	1	1	1	1	1	1		

Computer Graphic Software User Guide

· Install the Program

Click on setup.exe for the automatic installation, which should be provided with the product.

· Run the Program

Run the "Switch Operation Program.exe" and the program will open the configuration window. Select the correct Switch Group and select the specific Switch Type. Then click the "Connect" button and the program will establish the connection between PC and board.



SM and MM, 1260-1625nm, bidirectional






TTL Operation Instruction

· Create and edit testing time sequence


Add step: Click the "Add Step" button in the menu strip or click the "+(ADD)" button would both add a step to the Programmable Running Sheet.

Delete step: Click the "Delete Step" button in the menu strip or click the "-(DEL)" button would both delete a step in the Programmable Running Sheet.



Edit step: There are two things that you can modify for one step. One is the light path, and the other is the duration for each step. Double click the cell that you want to modify, and the program will allow you to modify the setting.





SM and MM, 1260-1625nm, bidirectional





DATASHEET

Command List

Command in Serial

The serial communication should be set in 115200 baud rate, none parity, 8 data bits, 1 stop bits.

Command in ASCII:

1. Check PN of device:

CMD: *PN<cr>

RTN: <cr><lf>AB.CD.EFGH<cr><lf>

2. Check SN of device:

CMD: *SN<cr>

RTN: <cr><lf>ABCDEFGHIJ<cr><lf>

3. Set Channel: CMD: *SWABC<cr>

RTN: <cr><lf>CHAN:ABC<cr><lf>

Example: *SW001<cr> RTN: <cr><lf>CHAN:001<cr><lf>

Note: <cr> is 0x0C in HEX, \n in ASCII



